



Technical Bulletin

Product: Toshiba DK 40, 280, 424 and 424i

Subject: Time Change Information

Issued By: Operations

Date Issued: November 2009 (updated)

Date Expires: None

To Set the Date: Usually thru the receptionist phone (ext.10 or 200)

1. Dial " # 6 5 1 "
2. Dial in the Date in the format "YYMMDD" (year, year, month, month, day, day. Enter a leading 0 for any single-digit month or day). For example: August 23, 2001 would be " 0 1 0 8 2 3 "
3. Press the "#" key
4. Press the "Spkr" button to hang up.

To Set the Time: Usually thru the receptionist phone (ext. 10 or 200)

1. Dial " # 6 5 2 "
2. Dial in the Time in the format "HHMMSS" (hour/minute/second in the 24-hour clock format. Enter a leading 0 for any single digit entered). For example: 5:21 PM would be "1 7 21 0 0"
3. Press the "#" key
4. Press the "Spkr" button to hang up.

To Set the Day: Usually thru the receptionist phone (ext. 10 or 200)

1. Dial " # 6 5 3 "
2. Dial the Day (Dial "1" for Sunday, "2" for Monday, "3" for Tuesday, "4" for Wednesday, "5" for Thursday, "6" for Friday, "7" for Saturday)
3. Press the "#" key
4. Press the "SPKR" button to hang up.

THIS DOCUMENT (INCLUDING ATTACHMENTS) CONTAINS PROPRIETARY AND CONFIDENTIAL INFORMATION, WHICH MAY ALSO BE SUBJECT TO NON-DISCLOSURE AGREEMENT TERMS. ACCORDINGLY, ANY DISCLOSURE OF THIS DOCUMENT OR THE INFORMATION IS PROHIBITED